

Decals will always install easier and look better if plastic is new and/or un-scratched. The following tips should help with the installation of your new graphics kit.

**Clean your plastic to remove all dirt, grease, oil, and adhesives with Contact Cleaner**

**New Plastic MUST be cleaned with Contact Cleaner to remove the shine.**

**Re-clean your plastic with rubbing alcohol.**

and a plain white paper towel. Make sure that all surfaces are clean and free of scratches and burred edges. Spray the number plate with water (NO WINDEX OR SOAP), and float the decal into place by laying it on the plastic and then sliding

it around for the best fit. Using a squeegee, squeegee out the water by starting from the middle and working it outward to the outer edge. Use a paper towel to dry excess water. **A HOT AIR BLOWER OR HAIR DRYER WILL NEED TO be used for difficult areas to better activate the adhesive and make the decal more flexible. Approx. 120 degrees**

**PLEASE BE PATIENT AND TAKE YOUR TIME.**

**Allow 24 hours dry-time at a temperature above 70 degrees Fahrenheit.**

**1a** 1) Line up the ball hole and then the back corner

**2a** 2) Squeegee the lower part of the graphic. In a sweeping motion. Push to back. Back to front (SEE BLACK AND WHITE)

Hold the bottom of the graphic "up" (or all the sides) as you go.

**4b**

4) Then squeegee the upper part of the graphic in sweeping motion. Front to back. Back to front (or back and forth) slowly below the angle of the pins (as shown) (Hold the graphic "up" (or all the pins) as you go.

5) Push upward with the squeegee and work out the wrinkles.



apply yellow dry

**2a**

3) When you get to the bottom use your squeegee to push down or out on the lower part of the graphic.

***Remember: If you are not pleased with your application, you'll still probably have to redo your application.***